


CTM-ONE WIRING OVERVIEW

>1.3.X Firmware

Single Point of Connection (Connected to Vehicle ECU)




Ensure that the following configurations are edited under the "gpio" and "vehicle" tabs on the device.

GPIO Configuration
Try to suspend when ignition is off for X seconds
0
0 to disable

Try to suspend when can0 is quiet for X seconds
300
0 to disable (THIS CONFIG WILL BE DEPRECATED, PLEASE AVOID USING)
Set VEH_IGN to LOW when SPEED & RPM is stable/missing for X seconds
120
0 to disable, used with setting below
Try to suspend when VEH_IGN is LOW for X seconds
180
0 to suspend immediately, used with setting above
<input checked="" type="checkbox"/> Wake on can0

Wired to Ignition (Connected to Vehicle ECU)




Ensure that the following configurations are edited under the "gpio" and "vehicle" tabs on the device.

GPIO Configuration
Try to suspend when ignition is off for X seconds
300
0 to disable

Try to suspend when can0 is quiet for X seconds
0
0 to disable (THIS CONFIG WILL BE DEPRECATED, PLEASE AVOID USING)
Set VEH_IGN to LOW when SPEED & RPM is stable/missing for X seconds
0
0 to disable, used with setting below
Try to suspend when VEH_IGN is LOW for X seconds
0
0 to suspend immediately, used with setting above
<input checked="" type="checkbox"/> Wake on can0

Wired to Battery (No ECU Connection)



Ensure that the following configurations are edited under the "gpio" and "vehicle" tabs on the device.

***Note:** green wire should be isolated and not connected to anything.

GPIO Configuration
Try to suspend when ignition is off for X seconds
300
0 to disable

CAN0 Configuration
Mode
DISEMBLED
2 WIRE: high-speed and medium-speed CAN

+1 (877) 985 2878

www.cypress.bc.ca // support@cypress.bc.ca

@CypressSLTNS f/CypressSolutionsInc in/Cypress-Solutions-Inc

CYPRESS
solutions

Cypress Solutions © | 3066 Beta Avenue | Burnaby, BC | V5G 4K4 | 604-294-4465